



INSTALLATION INSTRUCTIONS DOOR FRAME KITS

- 1) MEASURE HEIGHT OF DOOR KIT AND INSERT ADJUSTABLE UPPER SHELF APPROXIMATELY THAT DISTANCE FROM THE BASE SHELF.
- 2) INSERT DOOR KIT END PANEL INTO PLACE. FITS BETWEEN TWO BASE SHELVES OR BASE SHELF AND BASE END CLOSURE.
- 3) PLACE DOOR FRAME KIT ONTO BASE SHELF WITH ATTACHMENT STRAPS SWUNG OUT AS SHOWN.
- 4) ALIGN DOOR FRAME KIT VERTICAL TUBING MEMBER WITH THE HOLES IN THE DOOR KIT END PANEL, THEN DRILL AND POP RIVET TOGETHER USING SUPPLIED 3/16" POP RIVETS.
- 5) ATTACH BOTTOM MOUNTING BRACKETS OF DOOR FRAME KIT TO BASE SHELF USING #8 X 5/8" TEK SCREWS. (TYPICAL 2 PLACES).
- 6) ALIGN ATTACHMENT STRAPS OF DOOR KIT TO THE FIRST STIFFENER OF THE UPPER SHELF AND ATTACH WITH #8 X 5/8" TEK SCREWS (TYPICAL 2 PLACES).
- 7) REPEAT STEPS 1 THRU 6 AS NEEDED FOR ADJACENT DOOR FRAME KITS.
- 8) ATTACH A SECOND DOOR KIT END PANEL TO THE OTHER END OF THE DOOR FRAME KIT/RUN. THEN DRILL AND POP RIVET TOGETHER USING 3/16" POP RIVETS.

DOOR FRAME KIT INSTALLATION INSTRUCTIONS

STORFLEX

302 W. PLUTEBY STREET CORNING, NY 14830 PHONE: (607) 952-2137 FAX: (607) 952-7655

Note: Step (8) PAN HEAD TEK SCREWS MAY BE USED IN PLACE OF RIVOTS IF DESIRED